

Step 1. Assemble 2-piece(22" + 45") tighten x2 short knobs to secure. Attach columns to base using x2 small knobs each; pop on caps. Secure panels using x4 standoff caps each.

