


# TILT™ Graphic Stand

## set-up instructions

Remove 4 sections  
for 50"x50" and 36"x62".  
Cut cords to remove.




1




Loosen to move up  
and down. Stop  
at RED mark as that  
is the max. height.

2




Insert the 4 rods  
into the center hub.


3



Insert 4 hooks at end of rods into  
4 grommets in graphic, starting  
with the top grommets.



Loosen the **side knob** to tilt.



Loosen the **front knob** to rotate.



Package Contents.